Copyright © 2019 Radio Society of Great Britain, all rights reserved. www.rsgb.org

Notes:
1. Material 1/16″ thick aluminium
2. Primer: Degrease followed by one coat of cold cure acid etch primer
3. Finish: One or more coats of final colour - Revell or Humbrol enamel paint or similar
4. Smooth down each coat with very fine wet and dry paper and water
5. Apply lettering by Letraset of DECAdry
6. One very fine coat of acrylic clear matt or silk spray followed by one or more thicker coats